

A-M-T 1.8.8

# JOIN IN VIEWS

COMMAND GUIDE

Runs join operations for chosen element categories in selected project views.

A-M-T TOOL SERIES

**Configure.**
**Run.**
**Review.**

01 Understand the options

02 Follow the workflow

03 Check the result

# Understand the settings

### Views

Choose project views or restrict processing to selected views.

### Categories

Choose the element categories to include, such as walls, floors, ceilings, roofs, framing, columns and foundations.

### Only selected views

Use the current selection to limit the view set.

### Run

Start the join operation after choosing at least one view and category.

# How to use Join in Views

1. Choose the views to process.
2. Enable the element categories required for the join operation.
3. Confirm the selected scope and categories.
4. Run and review the resulting joins in the selected views.

**EXPECTED RESULT**

The command applies the selected join workflow to the chosen categories in the selected views.

# Before you finish

## QUICK CHECKLIST

- [ ] Correct model and active view
- [ ] Required types/templates are loaded
- [ ] Review settings before running
- [ ] Inspect the output in Revit
- [ ] Save a backup before bulk changes

## COMMAND FLOW

01 SELECT

02 CONFIGURE

03 RUN

04 VERIFY

## NOTES & LIMITATIONS

Join results depend on element geometry, category compatibility and Revit's join rules.